

Панти NEXIS SLIDE - ON с плавно прибиране



Артикул	Име	Кол.	Единица	Снимка
---------	-----	------	---------	--------

438.322.73.0015	Nexis 73 Slide-On VS	1	брой
-----------------	----------------------	---	------

438.322.74.0015	Nexis 73 Slide-On VS8 с дюбел	1	брой
-----------------	-------------------------------	---	------

438.322.73.0815	Nexis 74 Slide-OnVS	1	брой
-----------------	---------------------	---	------

438.322.74.0815	Nexis 74 Slide-On VS8 с дюбел	1	брой
-----------------	-------------------------------	---	------

314.393.52.0215	Баз.пластина Nexis Sl. 02	1	брой
-----------------	---------------------------	---	------

318.393.52.0015	Баз.пластина Nexis Sl. 02/ES	1	брой
-----------------	------------------------------	---	------

438.322.73.0815	Nexis 74 Slide-OnVS	1	брой
-----------------	---------------------	---	------


438.322.74.0815	Nexis 74 Slide-On VS8 с дюбел	1	брой
-----------------	-------------------------------	---	------

316.293.57.0815	Баз.пластина Nexis Sl. 08	1	брой
-----------------	---------------------------	---	------


924.200.40.0215	Nexis Softclose	1	брой
-----------------	-----------------	---	------




110°



110°




height-adjustable







height-adjustable






100°




height-adjustable






Панти NEXIS CLICK - ON с плавно прибиране

Артикул	Име	Кол.	Единица	Снимка
138.322.73.0015	Nexis 73 VS	1	брой	
138.322.74.0015	Nexis 73 VS8 с дюбел	1	брой	
138.322.73.0815	Nexis 74 VS	1	брой	
138.322.74.0815	Nexis 74 VS8 с дюбел	1	брой	
138.304.74.1515	Nexis 65 VS8 с дюбел	1	брой	
314.393.81.0215	Баз.пластина - еднокомпонентна NXB-L/RS-02	1	брой	
315.393.55.0215	Баз.пластина - двукомпонентна NXB-H/RS-02	1	брой	
924.200.40.0215	Nexis Softclose	1	брой	
924.200.40.7074	Nexis illuxo	1	брой	






Панти NEXIS CLICK - ON - Специални панти с плавно прибиране

138.405.74.9615	Nexis 33 VS8 с дюбел	1	брой	
138.405.73.0815	Nexis 43/+45 VS	1	брой	
924.200.40.0215	Nexis Softclose	1	брой	

70139-10	Nexis 21 VZ	1	брой	  
70121-08	Nexis 93 VZ с дюбел	1	брой	
70122-08	Nexis 94 VZ с дюбел	1	брой	
70194-06	Nexis Softclose 170°	1	брой	
314.393.81.0215	Баз.пластина - еднокомпонентна NXB-L/RS-02	1	брой	  
315.393.55.0215	Баз.пластина - двукомпонентна NXB-H/RS-02	1	брой	



Панти NEXIS CLICK - ON - Специални панти

70135-06	Nexis 42/-45 VS	1	брой	 
70133-06	Nexis 43/+30 VS	1	брой	 
70131-010	Nexis 43/+45 VS	1	брой	 

Панти NEXIS CLICK - ON - Стъклени врати Ф26 мм

146.017.93.0084	Nexis 53 GL 95	1	брой	  
70142-06	Nexis 54 GL 95	1	брой	
146.117.93.1584	Nexis 55 GL 95	1	брой	

Панти NEXIS CLICK - ON - Алюминиеви врати

70144-14	Nexis 13 AZ 95	1	брой	  
70145-14	Nexis 14 AZ 95	1	брой	
70146-06	Nexis 15 AZ 95	1	брой	
70195-06	Nexis Softclose за алум.рамка 20 мм	1	компл.	










MAET

G*GRASS®

Панти NEXIS SENSO TOUCH



Артикул	Име	Кол.	Единица	Снимка
70151-08	TL Nexis 73 VS8 с дюбел без пружина	1	брой	  110°
70152-08	TL Nexis 74 VS8 с дюбел без пружина	1	брой	  110°
70148-08	TL Nexis 65 VS8 с дюбел без пружина	1	брой	  100°
314.393.81.0215	Баз.пластина - еднокомпонентна NXB-L/RS-02	1	брой	 
315.393.55.0215	Баз.пластина - двукомпонентна NXB-H/RS-02	1	брой	
68873-06	SENSO TOUCH	1	компл.	  
63309-42	Пластина права	1	компл.	 
63310-42	Пластина 28/37	1	брой	